

Strataglass Warranty

We stand behind Strataglass with a 2-Year "No Worries" Performance Warranty. Strataglass has useful life expectancy of many more years when properly cleaned and maintained using Strataglass Protective Cleaner and Strataglass Protective Polish by IMAR.



Available at:

check availability on www.suretex.com



LEGENDARY CLEAR FOR MARINE ENCLOSURES



Strataglass® and CrystalClear are the finest yacht enclosure clear vinyl brands in the marine industry. Strataglass is the leading brand of enclosure clear vinyl featuring VueShield®, a proprietary scratch resistant coating. It is the premium choice for enclosure curtains worldwide. Available in 20, 30, 40 and 60 mil.

Exceptional Scratch Resistant Surface

Features a highly engineered superior scratch resistant coating called Strataglass VueShield, which inhibits fine line scratches. VueShield seals and protects the vinyl, maintaining its optimum durability, flexibility and extends the life of the Strataglass panels.

Strataglass Clear

Strataglass is engineered with a distinctive antiglare additive to enhance clarity, reduce sun glare and improve low light visibility.

Hardy Resistance to Over spray, Runoff and Pollutants

Clear vinyl curtains are susceptible to streaking from the hardware on your Bimini top or run off points of your boat top. These contaminants can create permanent imperfections in your enclosure panels. Our highly engineered Strataglass VueShield surface treatment chemistry resists these elements from etching the surface of your Strataglass Clear enclosure.

Strataglass Longevity

The benefit of Strataglass technology, precision manufacturing and VueShield surface treatment is obvious, you will see more clearly through your marine enclosure for a longer period of time. The exceptional Total Cost of Ownership of our solution delivers to you an increased useful life of your marine enclosure and reduces the frequency of expensive replacement common to other products.

Strataglass Care and Maintenance

To properly clean and maintain your Strataglass products we recommend using Strataglass Protective Cleaner and Strataglass Protective Polish as described below. Both products are by IMAR and available through your Strataglass provider or favorite retail marine store. Use of non-authorized cleaners or protectants may damage the Strataglass and void the warranty.

ALWAYS use Strataglass Protective Cleaner to immediately remove harmful liquids, creams, chemicals or sprays that contact the Strataglass surface. It is important to store a bottle of Strataglass Protective Cleaner on the boat for spot cleaning.

Rinsing Strataglass Curtains

Each time you use the boat, flush the curtains thoroughly with clear water to rinse away any salt or environmental abrasives. Air dry or use a high quality chamois or a microfiber towel.

Cleaning Strataglass Curtains

Every 1-2 weeks spray Strataglass Protective Cleaner directly on the inside and outside surfaces of the Strataglass or onto a soft cotton or micro fiber cloth. Gently wipe the Strataglass surface to clean. If necessary, buff dry with another dry clean cloth.

Polishing Strataglass Curtains

Every 1-2 months apply a light coat of Strataglass Protective Polish on both the inside and outside surfaces with small, light circular motions using a soft cotton cloth or applicator pad. Allow the polish to quickly dry. Lightly buff with a dry soft cotton or micro fiber cloth to a sparkling smooth shine.

LEGENDARY CLEAR FOR MARINE ENCLOSURES



A Subsidiary of Herculite Products, Inc.